
Healthcare Recliner Features




Infinite Position Non-Locking Back

Patients can adjust seating and back positions to their exact preferences through simple body movement.



Infinite Position Locking Back Lever

Infinite Position Locking Back allows patient/caregivers to lock back in any recline position.
Locking Back Lever is located on the inside of the left arm (facing).



Room Saver

Room Saver recliners sits within 5" of the wall & still fully reclines. Patients/Visitors can adjust seating and back positions to their exact preferences through simple body movement.




LiquiCell is standard on all La-Z-Boy Contract Furniture recliner seats. For more information please see page 110.



Quick Removable Back

(5025/5125 & 5027/5127 Models Only)
Recliners are standard with
removable back for easy
cleanability for infectious
disease control on select
models.




Recliner Handle

Recliners are standard with left side (facing) black handle. Recliner handle assists weakened occupants with footrest elevation. No need to push on back to open recliner footrest.




Padded Push bar

All mobile recliners feature padded push bar for ease of movement.




3" Swivel Locking Casters

(5027/5127/1307/1309 Models Only)
Recliners are standard with
three-3" swivel locking casters
and one-3" rigid locking caster
located in the front of the
recliner. Optional swivel
locking caster can be
exchanged for rigid locking
caster.



Rocker/Lock Mechanism

(5027/5127 Models Only)
The rocker recliner features a locking mechanism that locks the rocker making it easy on the patient for entering/exiting the chair and also during transport.



Heat/Heat & Massage Recliners


(5025/5125 & 5027/5127 Models Only) Heat (H) and Heat & Massage (HM) Control is located on the inside left arm (facing).

Healthcare Recliner Options




Adjustable Headrest Pillow (AHP)

Adjustable Headrest Pillow gives additional comfort to a patient or visitor. Adjustable Headrest Pillow requires 1 yard of fabric




Quick Release Bracket (QR)

(5025/5125 & 5027/5127 Models Only)
Quick Release Bracket is
mounted into metal insert nuts
and used with IV Pole and
Oxygen Tank Holder.




IV Pole and Bracket (IV)

(5025/5125 & 5027/5127 Models Only)
IV pole and bracket is positioned
on the recliner arm toward the
back of the chair. Dual IV Poles
(DP) also available.



Foley Bag Holder (FBH)

(5025/5125 & 5027/5127 Models Only)
Accommodates Foley bags and other drainage bags and closes flush with chair when not in use. Located on opposite arm from the handle toward the front of the chair.



Urine Bag Hook (UH)

(5025/5125 & 5027/5127 Models Only) Accommodates Foley bags and other drainage bags. Located on arm opposite from the handle.



Foot Tray (FT5)

(5025/5125 & 5027/5127 Models Only) Pull out foot tray easily slides out to support patient's feet during transport. (Not intended as a step)



Oxygen Tank Holder (OTH)

(5025/5125 & 5027/5127 Models Only) Oxygen Tank Holder is placed on outside right arm (facing) toward the back of the chair.